

E-FIELD PROBE

EF6092

# Measuring electric fields from 100 MHz to 60 GHz

using instruments in the NBM-500 family

- ▲ **General public and occupational field exposure**
- ▲ **Broad frequency range with high dynamic range**
- ▲ **Isotropic (non-directional) measurement**

The probe contains three orthogonally arranged dipoles with detector diodes. The diode voltages each correspond to the RMS value of the spatial components. The isotropic measurement result is obtained by addition within the probe.

## APPLICATIONS

The probe detects electric fields from 100 MHz up to 60 GHz. This frequency range covers almost the entire range of high frequency communications, right up to mobile radio and satellite links. The linearity and sensitivity of the probe ensure its suitability for checking human safety limit values in the occupational and general public environments.

## PROPERTIES

The probe is designed with mechanical and electrical properties ideal for field use. The probe head is made of foam material to provide effective protection for the sensors, while having excellent RF characteristics. The detector elements are also largely protected against overload, since their destruction limit is well above all the human safety limit values.

## CALIBRATION

The probe is calibrated at several frequencies. The correction values are stored in an EPROM in the probe and are automatically taken into account by the NBM instrument. Calibrated accuracy is thus obtained regardless of the combination of probe and instrument.



## SPECIFICATIONS <sup>a</sup>

Probe EF6092	Electric (E-)Field	
Frequency range <sup>(b)</sup>	100 MHz to 60 GHz	
Type of frequency response	Flat	
Measurement range	0.7 to 400 V/m (CW) 0.7 to 61.4 V/m (True RMS)	130 nW/cm <sup>2</sup> to 42 mW/cm <sup>2</sup> (CW) 130 nW/cm <sup>2</sup> to 1 mW/cm <sup>2</sup> (True RMS)
Dynamic range	55 dB	
CW damage level	1600 V/m	700 mW/cm <sup>2</sup>
Peak damage level <sup>(c)</sup>	1900 V/m	1 W/cm <sup>2</sup>
Sensor type	Diode based system	
Directivity	Isotropic (Tri-axial)	
Readout mode / spatial assessment	Combined 3-axis (RSS)	
<b>UNCERTAINTY</b>		
Flatness of frequency response <sup>(d)</sup> Calibration uncertainty not included	±3 dB (300 MHz to 40 GHz) +3/-6 dB (100 MHz to 60 GHz)	
Linearity Referred to 0.2 mW/cm <sup>2</sup> (27.5 V/m)	±3 dB (1 to 2 V/m) ±1 dB (2 to 250 V/m) ±2 dB (250 to 400 V/m)	±3 dB (0.26 to 1 μW/cm <sup>2</sup> ) ±1 dB (1 μW/cm <sup>2</sup> to 16.5 mW/cm <sup>2</sup> ) ±2 dB (16.5 mW/cm <sup>2</sup> to 42 mW/cm <sup>2</sup> )
Isotropic response <sup>(e)</sup>	±1.25 dB (< 10 GHz) ±2 dB (10 GHz to 26.5 GHz) ±2 dB typ. (> 26.5 GHz)	
Temperature response	±0.9 dB (-0.03 dB/K) @ f = 2.45 GHz	
<b>GENERAL SPECIFICATIONS</b>		
Calibration frequencies	100/ 200/ 300/ 500/ 750 MHz 1/ 1.8/ 2.45/ 3/ 4/ 5/ 6/ 8.2/ 10/ 11/ 18/ 26.5/ 40/ 45.5/ 60 GHz	
Recommended calibration interval	24 months	
Temperature range		
Operating	-10 °C to +50 °C	
Non-operating (transport)	-40 °C to +70 °C	
Humidity	5 to 95 % RH @ ≤ 28 °C	≤ 26 g/m <sup>3</sup> absolute humidity
Size	318 mm x 66 mm Ø	
Weight	90 g	
Compatibility	NBM-500 series meters	
Country of origin	Germany	

(a) Unless otherwise noted specifications apply at reference condition: device in far-field of source, ambient temperature 23±3 °C, relative air humidity 40 % to 60 %, sinusoidal signal

(b) Cutoff frequency at approx. -6 dB

(c) Pulse length 1μsec, duty cycle 1:100

(d) Frequency response can be compensated for by the use of correction factors stored in the probe memory

(e) Results are calculated from the maximum and minimum response obtained during the full revolution about the stem of the probe, oriented 54.7° to the electric field vector.

## ORDERING INFORMATION

	Part number
Probe EF6092, E-field for NBM, 100 MHz – 60 GHz, isotropic	2402/17B
Probe EF6092, E-field, ACC - with accredited (DAkKS) calibration up to 18 GHz, basic unit required	2402/17B/ACC

**Narda Safety Test Solutions GmbH**  
Sandwiesenstrasse 7  
72793 Pfullingen, Germany  
Phone +49 7121 97 32 0  
info@narda-sts.com

**Narda Safety Test Solutions**  
North America Representative Office  
435 Moreland Road  
Hauppauge, NY11788, USA  
Phone +1 631 231 1700  
info@narda-sts.com

**Narda Safety Test Solutions S.r.l.**  
Via Rimini, 22  
20142 Milano, Italy  
Phone +39 0258188 1  
nardait.support@narda-sts.it

**Narda Safety Test Solutions GmbH**  
Beijing Representative Office  
Xiyuan Hotel, No. 1 Sanlihe Road, Haidian  
100044 Beijing, China  
Phone +86 10 6830 5870  
support@narda-sts.cn

[www.narda-sts.com](http://www.narda-sts.com)

© Names and Logo are registered trademarks of Narda Safety Test Solutions GmbH - Trade names are trademarks of the owners.